



## Get the most out of your CROS II system

CROS II on poorer hearing ear	Hearing aid on better hearing ear	Benefits of performance level
		<p><b>V90</b></p> <ul style="list-style-type: none"> <li>Understand in noisy situations (activated automatically)</li> <li>Understand in echoey places</li> <li>Understand in the car</li> <li>Comfort in noisy situations</li> <li>Restore sound awareness from the poorer hearing ear</li> <li>Understand in quiet situations</li> </ul>
		<p><b>V70</b></p> <ul style="list-style-type: none"> <li>Understand in noisy situations (activated manually)</li> <li>Comfort in noisy situations</li> <li>Restore sound awareness from the poorer hearing ear</li> <li>Understand in quiet situations</li> </ul>
		<p><b>V50</b></p> <ul style="list-style-type: none"> <li>Comfort in noisy situations</li> <li>Restore sound awareness from the poorer hearing ear</li> <li>Understand in quiet situations</li> </ul>
		<p><b>V30</b></p> <ul style="list-style-type: none"> <li>Restore sound awareness from the poorer hearing ear</li> <li>Understand in quiet situations</li> </ul>

# Phonak CROS II features at a glance

Hearing aid Performance level	V90	V70	V50	V30
Microphone mode hearing aid	StereoZoom (automatic)	StereoZoom (manual)	UltraZoom Standard	UltraZoom Essential
Microphone mode CROS II			Real Ear Sound*/ Omnidirectional	Omnidirectional
Channels	20	16	12	8
Automatic programs	5	4	3	2

\*RIC models only



**PHONAK**  
life is on