

# Phonak Conversation Set

Quick setup guide / Schnellstartanleitung


Guide d'installation rapide / Guía rápida de instalación



**PHONAK**  
life is on


1

Charging  
Aufladen  
Charger  
Cargar



Or  
Oder  
Ou  
O bien


ComPilot Air II




RemoteMic

Wearing / Tragen / Porter / Llevar

ComPilot Air II




RemoteMic





Switching On  
Einschalten  
Mise en marche  
Encender


RemoteMic




ComPilot Air II



Solid blue  
Konstant blau  
Bleu continu  
Azul fijo



Usage  
Benutzung  
Utilisation  
Utilización




ComPilot Air II

RemoteMic



Pause / Resume  
Pause / Fortsetzen  
Pause / Continuer  
Pausa / Reanudar



Volume setting  
Lautstärke einstellen  
Réglage du volume  
Ajuste de volumen



Off

RemoteMic



Off

ComPilot Air II

The Phonak RemoteMic user guide will give you detailed information about the setup.

Die Phonak RemoteMic Gebrauchsanweisung informiert detailliert über den Gebrauch.

Le mode d'emploi Phonak RemoteMic vous donnera des informations détaillées sur l'utilisation.

Las instrucciones de uso del Phonak RemoteMic le darán una información más detallada sobre su uso.

## LED status



On  
Ein  
Marche  
Encendido



Low battery  
Niedriger Batteriestand  
Accumulateur faible  
Pila baja



Audio transmission  
Tonübertragung  
Transmission audio  
Transmisión audio



Pause mode  
Pause Modus  
Pause  
Pausa



Pairing mode  
Kopplungsmodus  
Couplage  
Modo de emparejamiento



Phonak AG  
Laubisrütistrasse 28  
CH-8712 Stäfa  
Switzerland

[www.phonak.com](http://www.phonak.com)

